

# SpeedRail System

with D-Dome 6.10 elevation



### Content

Tools overview	3
General safety information	L
• The following guidelines apply	5
· Planning with K2 Base	5
· Roof requirements	Ę
· Static requirements	Ę
· Important installation instructions	5
• Components	6
• Assembly	8
· Module fixation and distances mounting rails	8
· Installation SpeedRail base rails	9
· Assembly D-Dome 6 elevation	14
• Notes	17

#### Quality tested - several certifications

K2 Systems stands for secure connections, highest quality and precision. Our customers and business partners have known that for a long time. Independent institutes have tested, confirmed and certified our capabilities and components.

Please find our quality and product certificates under:

k2-systems.com


#### Übereinstimmungszeichen (Ü-Zeichen)



The SpeedRail system SpeedRail/SpeedClip has the German general building authority technical approval Z-14.4-603.

### **Tools overview**





**Dome Speed Spacer 2.25 / 2.50**  $\cdot$  2003253 / 2004129 Distance template for module lengths



#### **Digitale Toolbox**



**Do you already know our digital services?** Use our K2 Roof Check App now and record the first important data directly at the customer or project site.

Simply transfer the data to our online planning software K2 Base. Here you can plan your project easily, safely and quickly. You receive a detailed project report with assembly plan and static report.

The K2+ interface enables seamless project data transfer to the planning tools of other manufacturers. With the K2 DocuApp, project documentation is done quickly and easily – without annoying paperwork.

#### Get started and register now:

docuapp.k2-systems.com



base.k2-systems.com



## General safety information

Please note that our general mounting instructions must be followed at all times and can be viewed online at k2-systems.com.

- The equipment may only be installed and operated by qualified and adequately trained installers.
- Prior to installation, ensure that the product complies with on-site static loading requirements.
   For roof-mounted systems, the roof load-bearing capacity must always be checked.
- National and local building regulations and environmental requirements must be adhered to.
- Compliance with health and safety regulations, accident prevention guidelines and applicable standards is required.
  - Protective equipment such as safety helmet, boots and gloves must be worn.
  - Roofing works must be in accordance with roofing regulations utilising fall protection safeguards when eaves height exceeds 3 m.
  - At least two people must be present for the duration of the installation work in order to provide rapid assistance in the event of an emergency.
- K2 mounting systems are continuously developed and improved and the installation process may thereby change at any time. Prior to installation consult our website at k2-systems.com for up-to-date instructions.

We can send you the latest version on request.

- The assembly instructions of the module manufacturer must be adhered to.
- Equipotential bonding/grounding/earthing between individual parts is to be performed according to country specific standards, as well as national laws and regulations.

- At least one copy of the assembly instructions should be available on site throughout the duration of the installation.
- Failure to adhere to our general safety and assembly instructions and not using all system components,
   K2 is not liable for any resulting defects or damages.
   We do not accept liability for any damage resulting in the use of competitor's parts. Warranty is excluded in such cases.
- German law shall apply excluding the UN Convention on CISG. Place of venue is Stuttgart. Our General Terms of Business apply.
- If all safety instructions are adhered to and the system is correctly installed, there is a product warranty entitlement of 12 years! We strongly recommend reviewing our terms of guarantee, which can be viewed at k2-systems.com.

We will also send this information on request.

- Dismantling of the system is performed in reverse order to the assembly.
- K2 stainless steel components are available in different corrosion resistance classes. Each structure or component must be carefully checked for possible corrosion exposure.

# The following guidelines apply



This system can be used without further testing by K2 Systems in the following standard conditions. The system is also suitable for higher requirements. However, if a value exceeds the standard conditions, please contact K2 Systems.



#### Planning with K2 Base

Please plan a flat roof with covering "membrane, gravel..." and Dome 6 Classic/Classic LS system. Pay attention to the correct roof pitch and direction of the roof pitch. After completing the calculation, download the base file (your-file.k2o) and send it to service@k2-systems.de or your personal contact. Be sure to include the high bead spacing and width as well as the sheet metal quality and thickness.

We will then generate a manual calculation for you and send it to you.



#### **Roof requirements**

- This system can be installed on all trapezoidal sheet metal roofs with a roof pitch of up to 10°. The angle of elevation is 10°.
- · Sheet thickness:
  - aluminium ≥ 0,5 mmsteel ≥ 0,4 mm
- Minimum tensile strength aluminium:
   165 N/mm<sup>2</sup>; steel grade at least S235 GD.
- · Min. 22 mm high crest width



#### Static requirements


- Sufficient holding force of the roof covering on the supporting or substructure.
- For framed modules with a frame height of 30-50 mm
- Modules with the following dimensions can be used:
  - length 1448 2390 mmwidth 950 1170 mm




# Important installation instructions

On site, the general standards and regulations for lightning protection must be observed and, if necessary, a lightning protection concept must be drawn up by a specialist (use lightning protection clamp if necessary). Country-specific regulations must be observed.


- If the trapezoidal sheet metal is fastened with calottes, do not screw the SpeedClips onto them. Instead, mount all SpeedClips of this row offset on the trapezoidal sheet metal.
- At least every fourth or a quarter of all SpeedClips must be mounted rotated by 180°
- In the case of rail joints, it is imperative that the SpeedClips are fastened to the nearest high crests on both sides.
- After 8.80 m, a thermal break must be made. The minimum distance between two rails should be 3 cm.
- Attention. The modules must never be clamped over the thermal expansion joint.
- The number of SpeedLocks per module block can be taken from the static calculation of K2 Systems static calculation.
- The minimum distance from components/ MK2 to the end of the rail must be 20 mm.
- A minimum distance of 600 mm to the roof edge must be maintained for building heights > 5 m.
- Tightening torque of all module clamps
  14 Nm.
- After extraordinary events, such as storms, heavy rain, earthquakes, etc., the system must be inspected by a specialist company. If plastic deformation, e.g. in the area of the module clamps, or damage is detected during the inspection, these components must be replaced with new ones.
- Observe the module manufacturer's specifications for the clamping area and the installation of the modules (see the manufacturer's installation instructions).
   Check whether there is a manufacturer's approval for clamping in the corner area.
- Make sure that the drainage of rainwater is not obstructed.
- The lightning current carrying capacity of the system has been verified according to the test procedures of DIN EN 50164-1 (see "Recommendation potential equalisation and lightning protection").













# **Assembly**


#### Module fixation and distances mounting rails










### Installation SpeedRail base rails
































#### Assembly D-Dome 6 elevation



















# **Notes**






# **Notes**







# Vielen Dank, dass Sie sich für ein K2 Montagesystem entschieden haben.

Systeme von K2 Systems sind schnell und einfach zu montieren. Wir hoffen, diese Anleitung hat Ihnen dabei geholfen. Für Anregungen, Fragen oder Verbesserungsvorschläge stehen wir Ihnen gerne zur Verfügung. Alle Kontaktdaten finden Sie unter:

- k2-systems.com/kontakt
- Service-Hotline: +49 7159 42059-0

Es gelten unsere ALB; einzusehen unter: k2-systems.com



